








Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318817R	Air purge				
2	1	61200027AR	Cylinder cover	SN 2052131441			BT3-116-07/12
3	2	4191069B	Plate				
4	2	3801065R	Screw				
5	2	3819036R	Washer				
6	1	3916006R	Washer				
7	1	61200061R	Muffler				
8	1	61200063R	Deflector				
9	1	3055115	Spark plug				
10	1	61330095R	Gasket				
11	2	4196166R	Piston ring				BT3-114-05/12
12	2	004900061R	Ring				BT3-114-05/12
13	1	50110047R	Piston pin				BT3-114-05/12
14	1	61212004B	Piston assy Ø38	SN 2051076511			BT3-114-05/12
15	1	61212005A	Complete cylinder Ø38	SN 2051076511			BT3-114-05/12
16	1	50110044R	Thrust bearing				
17	2	50110043AR	Spacer				
18	1	61200001R	Crankshaft				
19	1	61200064R	Stopper				
20	1	61350210	Crankcase assy				
21	1	3860096	Screw				
22	2	094000006R	Bearing				
23	1	61200006AR	Gasket				
24	2	094000099R	Seal ring				
25	4	094000101R	Screw				
26	4	3833073R	Washer				
27	2	3023008R	Plug				
28	1	3916005R	Washer				
29	1	3819006R	Washer				
30	1	3801010R	Screw				
31	2	3960030	Screw				
32	1	3960069AR	Screw				
33	1	61202038AR	Gasket set				
35	1	61330079R	Cover	SN 2052131441			BT3-116-07/12
36	3	3893009R	Screw	SN 2052131441			BT3-116-07/12
37	1	61330080	Cylinder cover	SN 2052131441			BT3-116-07/12




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61200258R	Starter assy				BT3-097-07/10
2	1	61200015R	Starter handle				BT3-097-07/10
3	1	56520087R	Starter rope				BT3-097-07/10
4	6	3801010R	Screw				BT3-097-07/10
5	4	3916005R	Washer				BT3-097-07/10
6	1	004000132R	Spring				BT3-097-07/10
7	1	56520038AR	Pulley				BT3-097-07/10
8	1	3027005R	Ring				BT3-097-07/10
9	1	56520039AR	Shaft joint				BT3-097-07/10
10	1	56520040AR	Plate				BT3-097-07/10
11	1	3918020R	Washer				BT3-097-07/10
12	1	61200012AR	Spark plug cap				
13	1	61200062AR	Clutch driver				BT3-097-07/10
14	1	61250015BR	Ignition coil				
15	1	61250047R	Cable				
16	2	3801013R	Screw				
17	2	3819006R	Washer				
18	1	3912009	Nut				
19	1	3818011A	Washer				
20	1	61250014AR	Flywheel				
21	2	61200192AR	Adaptor				
22	2	3801015R	Screw				
23	1	50050127	Spring				
24	2	3914003R	Nut				
25	1	4196038	Bushing				
26	1	4196037R	Sleeve				
27	1	3024015	Snap ring				
28	1	61200031AR	Starter case				
29	1	3035042R	Bearing				
30	1	3025022R	Seeger				
31	1	4191030R	Clutch drum				
32	1	4191027FR	Pin				
33	1	4191028R	Spring				
34	1	4191153AR	Clutch				
35	1	072700089R	Bushing				BT3-097-07/10
36	2	3064010	Washer				BT3-097-07/10
37	2	3024007	Ring				BT3-097-07/10
38	2	4191017A	Spring				BT3-097-07/10
39	1	61200260	Starter kit assy				BT3-097-07/10
40	2	4191016R	Pawl				BT3-097-07/10
41	1	61252002R	Clutch driver				BT3-097-07/10
42	1	4191018BR	Starter pulley				BT3-097-07/10



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61200019AR	Gasket				
2	1	61200198	Insulator				
3	2	3801015R	Screw				
4	1	61212062	Complete support		SN 2053508856		BT3-124-04/14
5	1	61200196AR	Gasket				
6	1	2318765AR	Carburetor WT-869A		SN 2053508856		BT3-124-04/14
6	1	2318735CR	Carburetor WT-870B	SN 2053508857			BT3-124-04/14
7	1	61200025BR	Air filter				BT3-124-04/14
8	1	61200026R	Cover		SN 2053508856		BT3-124-04/14
9	1	61200028BR	Complete tank				
10	1	4098377R	Band				
11	1	61200092AR	Tube				
12	1	61200093R	Tube				
13	1	4161211R	Bush				
14	1	61070011AR	Breather valve				
15	1	61250228R	Tube				
16	1	61070079R	Tank cap				
17	1	61070006R	Gasket				
18	1	094600450R	Fuel filter				
19	1	61200057R	Stand				
20	5	3819006R	Washer				
21	5	3918005	Washer				
22	1	3801013R	Screw				
23	2	61052009BR	Screw				
24	1	61200024R	Lever				BT3-124-04/14
25	1	3960069AR	Screw				
26	1	61200023AR	Shutter		SN 2053508856		BT3-124-04/14
27	1	4120070	Washer				
28	4	61200128R	Spacer				
29	4	3916008R	Washer				
30	1	61200129R	Spring				
31	4	3801016R	Screw				
32	1	61202038AR	Gasket set				
33	1	61200091R	Tube				
34	1	61200204AR	Shutter	SN 2053508857			BT3-124-04/14
35	1	3916022R	Washer	SN 2053508857			BT3-124-04/14
36	1	3960145R	Screw	SN 2053508857			BT3-124-04/14
37	1	61210130	Air filter support set	SN 2053508857			BT3-124-04/14
38	1	61200205R	Filter cover	SN 2053508857			BT3-124-04/14
39	1	61210047R	Guard				











Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61250054R	Pin				BT3-098-07/10
2	2	3801015R	Screw				
3	2	61170132R	Grommet				
4	1	4179094A	Knob				
5	5	3801013R	Screw				
6	1	61040145R	Hub				
7	1	074000183AR	Clamp	06/2011			BT3-106-04/11
8	1	3960021	Screw				
9	1	61110074R	Guard				BT3-098-07/10
10	1	61252049R	Tube Ø28				
11	8	3914003R	Nut				
12	1	2317021R	Switch				
13	1	4138358R	Button				
14	1	4138360R	Spring				
15	1	4174246AR	Lever				
16	1	4174245CR	Throttle lever				
17	1	4138361R	Spring				
18	1	61040066R	Spacer				
19	1	4100098BR	Spring				
20	2	3960029	Screw				
21	1	3801016R	Screw				
22	1	61040140R	Knob				
23	1	61200049R	Handlebar				
24	1	61040131R	Handle				
25	1	61200047R	Throttle cable				
26	1	61200046R	Cable				
27	1	61200048R	Handlebar				
28	1	4098116R	Drive shaft				
29	2	074000035R	AV-mount				
30	1	3901008R	Screw				
31	1	4138359R	Button				
32	1	61250287A	Kegelradantrieb Ø28				BT3-098-07/10
33	1	3024012	Ring				
34	1	3035040R	Bearing				
35	1	4179194R	Band Ø28				
36	1	3025019	Ring				
37	1	4179089R	Flange				
38	1	3034019	Bearing				
39	1	4138311A	Ring				
40	1	3025009	Ring				
41	1	61040133A	Bevel gear set				
42	1	61040071R	Cap				
43	1	61040144R	Gear case				
44	1	3034218	Bearing				
45	1	61110075R	Nut				BT3-098-07/10
46	1	3034012R	Bearing				
47	1	3025022R	Seeger				
48	1	3050018R	Seal ring				
49	2	3819006R	Washer				
50	1	072700264CR	Clamp	06/2011			BT3-106-04/11




15 ■ KIT RIPARAZIONE
REPAIR KIT

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50010141	Screw				
2	2	095000164	Ring				
3	1	072700211	Shutter				
4	1	2318211	Pin				
5	1	2318737	Shaft				
6	1	072700347	Spring				
7	1	2318837	Adjust. screw				
8	1	074000240	Adjust. screw				
9	1	2318631	Adjust. screw				
10	1	2318191	Cover				
11	4	035000162	Screw				
12	1	003300197	Screw				
13	1	375100087	Cover				
14	1	003300201	Spindle				
15	1	2318671	Repair kit				
16	1	094600148	Spring				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	-	-	Not available for this product			Sostituita da testina completa codice 63019016 (inserto maschio), 63019018 (inserto femmina); Replaced by complet head p/n 63019016 (male insert), 63019018 (female insert)	
2	1	3960040R	Screw				
3	1	4174278	Plate				
4	4	3802004CR	Screw				
5	1	4174283AR	Skirt w/blade				
6	1	4174275R	Blade				
7	1	4192048CR	Disc guard				
8	2	4199005AR	Bushing				
9	1	4199008B	Insert (male)				
10	1	4199004	Spring				
11	1	4199042R	Nylon spool Ø3				
12	1	4095673B	3-tooth blade				
13	1	4199035BR	Cover				
14	1	61052031R	Tool kit				
15	1	61200106R	Harness				
16	1	61212053	Labels kit				
17	-	-	Not available for this product			Sostituita da testina completa codice 63019016 (inserto maschio), 63019018 (inserto femmina); Replaced by complet head p/n 63019016 (male insert), 63019018 (female insert)	
18	1	61110076	Insert (female)				BT3-098-07/10
19	1	4199052	Nylon spool				
20	1	4199026A	Cover				
21	1	4199046	Cover				
22	1	63019018	Compl. nylon head Ø3			Inserto femmina; Female insert	BT3-098-07/10
22	1	63019016	Compl. nylon head Ø3			Inserto maschio; Male insert	



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	63129001	Load & Go nylon head			Filo D.2,4 mm; Nylon line D.2,4 mm	
1	1	63129003	Load & Go nylon head			Filo D.3,0 mm; Nylon line D.3,0 mm	
2	1	63120041R	Insert				
3	1	63120040R	Nut				
4	1	63120031R	Kit spring				
5	1	63120020R	Nylon spool				
6	1	63120007R	Knob				
7	2	63120001R	Bushing				
8	1	63120005R	Cover				
9	1	63120042R	Insert				